
Example of LOAD MODULE orientation





To achieve good weighing results, always use flexible connections to the vessel and check that no ladders or other arrangements connect the weighed vessel to surrounding foundation, walls or roof.

Vishay Nobel


Vishay Nobel AB
Box 423, SE-691 27 Karlskoga, Sweden
Phone +46 586 63000, Fax +46 586 63099
e-mail: info.se@vishaynobel.com , www.vishaynobel.com

Advices for mounting KIS 8









5



Mark the hole pattern and drill.

Mount the bolts; re-position
the LOAD MODULES and the vessel.

2


Attach YOKES under the vessel supports and position the vessel on the LOAD MODULES. Observe that the bedding should be horizontal.

The load module cables should face the centre of the vessel.


Check measure x.



6




Check again measure **x** and the lateral play between YOKE and LOAD CELL.



3

Recommended loading point




	kN	x (mm)
	1 kN	37
	2 kN	37
	5 kN	65
-	10 kN	65
	20 kN	65
	50 kN	84
	100 kN	105
	200 kN	128

7


For installations with four LOAD MODULES or more, the LOAD MODULE output signals should be checked.

Add shims between vessel support and YOKE to achieve similar signal levels.



4

Check that there is a lateral play between YOKE and LOAD CELL.



Important notice:

Do not perform any welding with the LOAD MODULE in place.